

GRUNDIG SERVICE MANUAL



Service Manual

Sach-Nr./Part No.
72010-017.50

Zusätzlich erforderliche Unterlagen für den Komplettservice:

Additionally required Service Manuals for the Complete Service:

Service Manual

Sicherheit
Safety

Sach-Nr./Part No.
72010-800.00



D Btx * 32700 #

GRUNDIG PASSION

CUC 6450

TV-MAX E 55-700 TOP/LOG (9.21381-01 / G.CB 3575)
TV-MAX E 55-700/9 TOP/LOG (9.21381-02 / G.CB 4575)

TP 720



MEGALOGIC

Allgemeiner Teil

General Part

Meßgeräte / Meßmittel

Regeltrenntrafo	Meß-/Wobbelsender
Farbgenerator	Oszilloskop
DC-Voltmeter	NF-Voltmeter
NF-Generator	Frequenzzähler

Test Equipment / Aids

Variable isolating transformer	Test/Sweep Generator
Colour Generator	Oscilloscope
DC Voltmeter	AF Voltmeter
AF Generator	Frequency counter

Beachten Sie bitte das Grundig Meßtechnik-Programm, das Sie unter folgender Adresse erhalten:

Please note the Grundig Catalog "Test and Measuring Equipment" obtainable from:

Grundig electronics GmbH
Würzburger Str. 150
D-90766 Fürth/Bay.
Tel.0911/703-0
Telefax 0911/703-4479

Grundig electronics GmbH
Würzburger Str. 150
D-90766 Fürth/Bay.
Tel.0911/703-0
Telefax 0911/703-4479

Modulübersicht

Module List

	E 55-700/9 TOP/LOG	E 55-700 TOP/LOG
Chassis	29701-095.02	29701-095.01
Tuner	29504-201.21	29504-201.21
ZF-Verstärker IF Amplifier	29504-162.56 29504-162.57	29504-102.56
NF-Baustein AF Module	29504-104.67	29504-104.67
Farb-Decoder Sync.-Baustein Colour Decoder Sync. Module	29504-165.67	29504-105.67
Bildrohrplatte CRT Panel	29305-122.03	29305-122.03
Bedieneinheit Control Unit	29501-082.01	29501-082.01
Cinchbuchsenplatte Cinch Socket Board	29305-008.30	29305-008.30
Abstimm- / Text -Baustein Tuning Text Modul	29504-103.80	29504-103.80
Fernbedienung TP 720 Remote Control TP 720	29642-059.06	29642-059.06
SAT-Baustein (nachrüstbar) SAT Module (retrofitable)	29504-106.22	29504-106.22

Technische Daten / Technical Data

	TV-MAX E 55-700 TOP/LOG	TV-MAX E 55-700/9 TOP/LOG
Bildröhre / Picture Tube		
Sichtbares Bild Visible picture	51cm	51cm
Bildschirmdiagonale Screen diagonale	55cm (21") Black Matrix	55cm (21") Black Matrix
Ablenkwinkel Deflection angle	90°	90°
Bildwechselfrequenz Vertical frequency	50Hz	50Hz
Elektronik / Electronic		
Programmspeicherplätze Programme positions	99 + 3 AV	99 + 3 AV
AV-Auswertung AV evaluation	auf jeden Programmplatz programmierbar / programmable for every program position	
Tuner	Kabeltuner-Raster 8MHz für Hyperband / cable tuner - 8MHz spacing for hyperband	
TV-Normen TV standards	PAL/NTSC 4.43MHz/B/G	Multinorm
Musikleistung Music power	100W	100W
Anschlüsse Front / Connections Front		
Kopfhörer Headphones	Stereo 6,3mm Buchse, Lautstärke regelbar, individuelle Tonkanalwahl bei 2-Ton-Empfang / Stereo 6.3mm socket, adjustable volume, individual channel selection with dual-sound broadcasts	
NF Stereo Ausgangs-Buchsen AF stereo output-sockets	2 x Cinch	2 x Cinch
Video IN (Stereo)	bei AV 3 Position in AV 3 position	bei AV 3 Position in AV 3 position
Anschlüsse Rückwand / Connections Rear Panel		
Euro AV (schwarz, black)	voll belegt mit RGB-Eingang fully wired with RGB-input	voll belegt mit RGB-Eingang fully wired with RGB-input
Euro AV (orange)	S-Video Megalogic	S-Video Megalogic
Netzteil / Mains Stage		
Netzspannung (Regelbereich) Mains voltage (variable)	165...265V	165...265V
Netzfrequenz Mains frequency	50 / 60Hz	50 / 60Hz
Leistungsaufnahme Power consumption	ca. 75W	ca. 75W
Standby	ca. 10W	ca. 10W

D Schaltplansymbole **GB** Circuit Diagram Symbols **F** Symboles schéma**I** Simboli sullo schema **E** Símbolos en los esquemas

	Feinabst. + / Fine tuning + / Réglage fine + / Sint. fine + / Sint. fina +		Kanalwahl / Channel selection / Sélection de canaux / Selez. canale / Selecccion canal
	Feinabst. - / Fine tuning - / Réglage fine - / Sint. fine - / Sint. fina -		Mittelpunkt-Lautsprecher / Center loudspeaker / Haut-parleur de centre / Alto parlante punto centrale / Altavoz del centro
	Lautstärke / Volume / Volume / Volume sonore / Volumen		Chip Adresse / Chip adress / Chip direction / Indiri. del chip / Direccion chip
	Referenz Lautstärke / Volume ref. volt. / Tens. de réf. vol. sonore / Tens di rif. volume / Tens. ref. volumen		Ton-Signal Cinch links / Audio signal cinch left / Signal audio cinch gauche / Segnale audio cinch sinistra / Señal audio cinch izquierda
	Balance / Balance / Balance / Balanciam. / Balance		Ton-Signal Cinch rechts / Audio signal cinch right / Signal audio cinch droit / Segnale audio cinch destra / Señal audio cinch derecha
	Suchlauf / Self seek / Recherche autom. / Sint. autom. / Sintonia automatica		Chroma S-VHS-Signal / Chroma S-VHS-Signal / Signal dégree de S-VHS / Croma segnale S-VHS / Señal croma S-VHS
	Farbton / Tint / Teinte / Tinta / Tinte		
	Helligkeit / Brightness / Luminosité / Luminosita / Brillo		Clock
	Kontrast / Contrast / Contraste / Contrasto / Contraste		
	Farbkontrast / Colour contrast / Contraste des couleurs / Contrasto colore / Contraste de color		Composite Sync. Imp. für VT / Composite sync pulse for TT / Imp. de sync. vidéo-composite pour TXT / Imp. hor. para Video Comp.
	Schutzschaltung / Protection circuit / Circuit de sécurité / Circuito di protezione / Circuito de protección		Kombiniertes Hor./vert. Sync. Signal 31250Hz/100Hz (Composite Sync.) / Combined hor./vert. sync signal 31250Hz/100Hz (Composite Sync) / Signal synchr. hor./vert. combiné 31250Hz/100Hz (Synchr. composé) / Segnale sincr. orizz./vert. 31250Hz/100Hz (Sincr. Composito) / Señal combinada sincr. hor./vert. 31250/100Hz (Sincr. compuesto)
	(Burst Key): Burstaustastimpuls / Burst blanking pulse / Impulsion de suppress. de burst / Imp. di soppress. del burst / Imp. supresion burst		Daten / Data / Données / Dati / Datos
	Ton-Signal / Audio signal / Signal audio / segnale audio / Señal audio		Verzögerungsleitung / Delay line / Ligne à retard / Linea di ritardo / Linea de retardo
	Ton-Signal links / Audio signal left / Signal audio gauche / Segnale audio sinistra / Señal audio izquierda		Freigabe ZF / IF Enable / Validation FI / Consenso FI / Autorización FI
	Ton-Signal rechts / Audio signal right / Signal audio droit / Segnale audio destra / Señal audio derecha		Freigabe FT / Finetuning enable / Autorisation Réglage fin / Abilitaz. Sintonia fine / Habilitacion Sintonia fina
	Tonsignal D2 Mac / Audio signal D2MAC / Signal audio D2MAC / Segnale audio D2MAC / Señal de sonido D2MAC /		Freigabe LED / LED enable / Autorisation LED / Abilitaz. LED / Habilitacion LED
	Tonsignal links D2 Mac / Audio signal left D2MAC / Signal audio gauche D2MAC / Segnale audio sinistro D2MAC / Señal de sonido izquierdo D2MAC /		Freigabe Ton / Sound enable / Autorisation son / Abilitaz. audio / Habilitacion sonido
	Tonsignal rechts D2 MAC / Audio signal right D2MAC / Signal audio droit D2MAC / Segnale audio destro D2MAC / Señal de sonido derecho D2MAC /		Audio-Signal EURO-AV links / Audio signal EURO-AV left / Signal audio EURO-AV gauche / Segnale audio EURO-AV sinistra / Señal audio izquierda EURO-AV
	Audio-Signal FS Gerät / Audio signal TV set / Signal audio téléviseur / Segnale audio TV / Señal audio TV		Audio-Signal EURO-AV rechts / Signal audio EURO-AV right / Signal audio EURO-AV droit / Segnale audio EURO-AV destra / Señal audio derecha EURO-AV
	Tonsignal VCR Gerät / Audio signal VCR unit / Signal audio magnétoscope / Segnale audio VCR / Señal audio VCR		Video-Signal EURO-AV / Video signal EURO-AV / Signal video EURO-AV / Segnale video EURO-AV / Señal video EURO-AV
	Blau-Signal / Blue signal / Signal bleu / Segnale blu / Señal azul		Farb-Signal / Chroma signal / Signal chroma / Segnale chroma / Señal croma
	Rechner Stop I²C Bus frei / Computer Stop I²C Bus is free / Microprocesseur stop I²C Bus disponible / Calcol. stop I²C Bus libero / Stop micropr. disponible		FBAS-Signal / CCVS signal / Signal vidéo composite / Segnale video composito / señal video compuesta
	Basisband / Baseband / Bande de base / Banda base / Banda base		FBAS-D2 MAC / D2MAC CCVS signal / Signal vidéo composite-D2MAC / FBAS-D2MAC / FBAS-D2MAC
	Blau-Signal extern / Signal blue external / Signal bleu externe / Segnale blu esterno / Señal azul externa		Basisband / Baseband / Bande de base / Banda base / Banda base
	Blau-Signal PIP / PIP Blue signal / Signal bleu PIP / Segnale blu PIP / Señal azul PIP		FBAS-Videotext / CCVS videotext / Signal vidéo composite-Télexte / FBAS-Televideo / FBAS-Teletexto
	Blau - Signal - 50Hz vert., 15625Hz hor. / Blue signal - 50Hz vert., 15625Hz hor. / Signal bleu - 50Hz vert., 15625Hz hor. / Segnale blu - 50Hz vert., 15625Hz hor. / Señal azul - 50Hz vert., 15625Hz hor.		FBAS Sync. Signal / CCVS sync signal / Signal sync. vidéo col. comp. / Segnal sincr. video col. comp. / Señal sincr. video compuesta
	Blau-Signal - 100Hz vert., 31250Hz hor. / Blue signal - 100Hz vert., 31250Hz hor. / Signal bleu - 100Hz vert., 31250Hz hor. / Segnale blu - 100Hz vert., 31250Hz hor. / Señal azul - 100Hz vert., 31250Hz hor.		FBAS Signal S-VHS / CCVS signal S-VHS / Signal vidéo col. comp. S-VHS / Segnal video col. comp. S-VHS / Señal video compuesta S-VHS
	B-Y -Signal - 50Hz vert., 15625Hz hor. / B-Y -Signal - 50Hz vert., 15625Hz hor. / Signal B-Y - 50Hz vert., 15625Hz hor. / Segnale B-Y - 50Hz vert., 15625Hz hor. / Señal B-Y - 50Hz vert., 15625Hz hor.		
	B-Y -Signal - 100Hz vert., 31250Hz hor. / B-Y -Signal - 100Hz vert., 31250Hz hor. / Signal B-Y - 100Hz vert., 31250Hz hor. / Segnale B-Y - 100Hz vert., 31250Hz hor. / Señal B-Y - 100Hz vert., 31250Hz hor.		

FH 	Hochspg. / EHT voltage / Haute tens. / Alta tens. / MAT	M	Speicher Taste / Memory button / Touche mémoire / Tasto di memoria / Puls. memoria
FRM	Rahmensignal / Frame signal / Signal d'encadrement / Segnale cornice / Señal de marco	NIC CLK	NICAM Clock / Clock NICAM / Horloge NICAM / Clock NICAM / Clock NICAM
FT	Feinabstimmung / Fine tuning / Reglage fin / Sint. fine / Sint. fina	NORM	Norm Taste / TV standard select button / touche de norme / Tasto norma / Puls. de norma
FU	FU-Signal / FU-signal / Signal FU / Segnale FU / Senal FU	OWA	Ost-West Ansteuerimpuls / East-west drive impuls / Impulsion de commande Est-Ouest / Impulso comando Est-Ovest / Impulso de control Este-Oeste
FV	FV-Signal / FV-signal / Signal FV / Segnale FV / Senal FV	P	Programm / Program / Programme / Programma / Programa
G	Grün-Signal / Green signal / Signal green external / Signal vert / Segnale verde / Señal verde	P/C	Programm-Kanalwahl / Program channel selection / Progr. sélection de canaux / Progr. selez. canale / Progr. selec. canal
G PIP	Grün-Signal PIP / Green signal PIP / Signal green PIP / Signal vert PIP / Segnale verde PIP / Señal verde PIP	PIP	Bild im Bild / Picture in picture / Image dans l'image / PIP / Imagen en la imagen
GEXT	Grün-Signal extern / Green signal vertical / Signal vert externe / Segnale verde esterno / Señal verde externa	P1	Progr. Taste / Progr. button / Touche Progr. / Tasto Progr. / Puls. Progr.
G/50	Grün-Signal - 50Hz vert., 15625Hz hor. / Green signal - 50Hz vert., 15625Hz hor. / Signal vert - 50Hz vert., 15625Hz hor. / Segnale verde - 50Hz vert., 15625Hz hor. / Señal verde - 50Hz vert., 15625Hz hor.	R	Rot-Signal / Red signal / Signal rouge / Segnale rosso / Señal roja
G/100	Grün-Signal - 100Hz vert., 31250Hz hor. / Green signal - 100Hz vert., 31250Hz hor. / Signal vert - 100Hz vert., 31250Hz hor. / Segnale verde - 100Hz vert., 31250Hz hor. / Señal verde - 100Hz vert., 31250Hz hor.	REMOTE	Fernbedienung / Remote control / Telecommande / Telecomando / Mando a distancia
GND - H 	Nullpunkt Heizung / Ground filament / Point neutre-Chauffage / Punto zero-Filamento / Punto medio filamento	R PIP	Rot-Signal PIP / Red signal PIP / Signal rouge PIP / Segnale rosso PIP / Señal roja PIP
HA	Horiz. Sync. Impuls / Horiz. Sync pulse / Impulsion synchro. horiz. / Impulso sincro orizzontale / Impulso de sinc. horiz.	REXT	Rot-Signal extern / Signal red external / Signal rouge externe / Segnale rosso esterno / Señal rojo externa
HDR	Horiz. Ansteuerimpuls / Horiz. drive pulse / Impulsion de commande horiz. / Impulso comando orizzontale / Impulso de control horiz.	R-Y/50	R-Y -Signal - 50Hz vert., 15625Hz hor. / R-Y -Signal - 50Hz vert., 15625Hz hor. / Signal R-Y - 50Hz vert., 15625Hz hor. / Segnale R-Y - 50Hz vert., 15625Hz hor. / Señal R-Y - 50Hz vert., 15625Hz hor.
HC	Horiz. Klemmimpuls / Horiz. clamp pulse / Impulsion de serrage horiz. / Impulso comando orizzontale / Impulso de garras horiz.	R-Y/100	R-Y -Signal - 100Hz vert., 31250Hz hor. / R-Y -Signal - 100Hz vert., 31250Hz hor. / Signal R-Y - 100Hz vert., 31250Hz hor. / Segnale R-Y - 100Hz vert., 31250Hz hor. / Señal R-Y - 100Hz vert., 31250Hz hor.
HFB	Horiz. Rückschlagimpuls / Horiz. flyback / Impulsion de retour horiz. / Impulso ritorno orizzontale / Impulso de retroceso horiz.	S	Sonderkanal / Special channel / Canal special / Canale speciale / Canal especial
HS	Hor. Sync. Impuls für VT / Hor. sync pulse for TT / Imp. de sync. hor. pour TXT / Imp. sincr. orizz. per Televideo / Imp. hor. para Video Comp.	SB	Strahlstrombegrenzung / Beam current lim. / Lim. cour. de faisceau / Lim. corr. di raggio / Corriente media de haz
I BEAM	Strahlstrom / Current beam / Current rayon / Corrente del irradire / Corriente de haz	SCL	I ² C-Bus Clock
ICL	I ² C Bus -Clock	SCL 100	Schneller I ² C-Bus Clock / I ² C-Bus clock high speed / I ² C-Bus grande vitesse / I ² C-Bus veloce / Clock del I ² C-Bus de alta velocidad
IR	Infrarot-Signal / Signal infrared / Signal infra-rouge / Segnale infrarosso / Señal infrarojo.	SDA	I ² C-Bus Daten / I ² C-Bus data / I ² C-Bus données / I ² C-Bus dati / I ² C-Bus datos
IM CLOCK	I ² C Bus -Clock	SHIFT VIDEO	Dynamische vert. Versch. 25Hz, aktiv bei Video u. Mix Betrieb / Dynam. vert. shift 25Hz, active on video and mix operation / Decal dynam. de l'image 25Hz, actif sur video et fonction. mixte / Spostam. vert. dinam. 25Hz, attivo con video e. funzionam. misto / Desplaz. dinamico vert. 25Hz, activo con video Y funciones mixtas
IM IDENT	I ² C Bus -Kennung / I ² C-Bus Identification / Identification I ² C-Bus / Ident. I ² C-Bus, Identification I ² C-Bus	SHIFT TEXT	Dynamische vert. Versch. 25Hz, aktiv bei Standbild u. VT / Dyn. vert. shift 25Hz, active on freeze-frame and Teletext / Decal dynam. de l'image 25Hz, actif sur arret image et Vidéotext (Antiope) / Spostam. vert. dinam. 25Hz, attivo con fermo immag. e Televideo / Desplaz. dinamico vert. 25Hz, activo con imagen parada Y Videotexto
IM RESET	I ² C Bus -Reset	SS	Schutzschaltung / Protection circuit / Cablage protecteur / Pot. de prot. / Circuito de proteccion
IR CLK	Infrarot Clock / Infrared clock / Signal I.R. horloge / Clock segnale R.I. / Clock infrarojos	SSB	Spitzenstrahlstrombegrenzung / Peak beam current limiting / Lim. de faisceau crete / Lim. corr. catod. di pico / Corrente pico de haz
IR DATA	Infrarot Signal / Infrared signal / Signal I.R. / Segnale infrarosso / Data infrarojos	SSC	Supersandcastle
IR VIDEO	Infrarot Signal Video / Infrared signal video / Signal I.R. video / Segnale infrarosso video / Data infrarojos video	SSC PIP	Supersandcastle PIP
KH AUDIO-L	Tonsignal Kopfhörer links / Audio signal headphone left / Signal audio gauche de casque / Segnale audio sinistra cuffia / Señal audio izquierda auriculares	SSC/100	Supersandcastle 100Hz vert., 31250Hz hor.
L	Lautstärke / Volume / Volume / Volume sonore / Volumen	SSC/SUR-ROUND	Supersandcastle 50Hz vert., 15625Hz hor.
LED	Leuchtdiode / Light emitting diode / Diode lumineuse / Diodo luminoso / Diodo luminescente	SYNC	Sync.-Signal / Sync.-Signal / Signal sync / Segnale sync. / Señal de sync.
KH AUDIO-R	Tonsignal Kopfhörer rechts / Audio signal headphone right / Signal audio droit de casque / Segnale audio sinistra cuffia / Señal audio derecha auriculares		

	Sync. BTX / Viewdata Sync / Sync. Télétex / Sincr. Videotel / Sincr. Videotexto		Schaltspg. Camera Wiedergabe / Switching volt. camera playback / Tens. commut. reprod. camera / Tens. commut. riproduz. telecam / Tens. conmut. reprod. camara
	Sync. VT / Sync. Teletext / Sync Vidéotexte / Sincr. Televideo / Sincr. Videotexto		Schaltspg. Datenbetr. / Switching volt. data mode / Tens. de commut. fonct. données / Tens. di commut. dati / Tens commut. datos
	Schwarzwert / Black level / Niveau du noir / Livello del nero / Nivel de negro		Schaltspg. U Data extern / Switching volt Data ext. / Tension de commutation U Data externe / Tens. di commutazione U-Data esterno / Tensión de conmutación externa U
	TEXT-Freigabe / TEXT enable / Autorisation TEXTE / Abilitaz. TELEVIDEO / Habilitation TEXTE		Schaltspg. Deemphasis / Switching volt. deemphasis / Tens. commut. desaccent. / Tens. commut. deenfasi / Tens. conmut. deenfasis
	Bei Zweitton, Ton 1 / On two channel sound, sound 1 / Pour double son, son 1 / In bicanale, audio 1 / En dual, sonido 1		Schaltspg. Dolby-Surround / Switching volt. Dolby-Surround / Tens. commut. Dolby-Surround / Tens. commut. di Dolby-Surround / Tens. de conmut. Dolby-Surround
	Bei Zweitton, Ton 2 / On two channel sound, sound 2 / Pour double son, son 2 / In bicanale, audio 2 / En dual, sonido 2		Schaltspg. D2MAC / Switching volt. D2MAC / Tension de commutation D2MAC / Tens. di commutazione D2MAC / Tensión de conmutación D2MAC
	Tieftöner / Woofer / Haut-parleur pour les frequences basses / Toni bassi / Sonido bajo		Schaltspg. EURO-AV / Switching volt. EURO-AV / Tens. de commut. EURO-AV / Tens. di commut. EURO-AV / Tens. conmut. EURO-AV
	Fokusspg. / Focussing volt. / Tens. de focalis. / Tens di focalizz. / Tens focalizacion		Schaltspg. EURO-AV-Cinch-Buchse / Switching volt. EURO-AV-Cinch socket / Tens. commut. prise Scart - Cinch / Tens. commut. presa Scart -Cinch / Tens. conmut. EURO-AV - Cinch
	Spg. Gitter 1 / Volt. grid 1 / Tens grille G 1 / Tens. griglia 1 / Tens. rejillas G 1		Schaltspannung für Video-Ausgang EURO-AV Buchse / Switch. voltage for video output EURO-AV socket / Tension de commut. pour sortie vidéo EURO-AV / Tension commut. per presa d'uscita video EURO-AV / Tension de conmut. para salida EURO-AV
	Hochspannung / High voltage / Haute tension / EAT / Alte tension		Schaltspg. HIFI / Switching voltage HIFI / Tens. de commut. HIFI / Tens di commut. HIFI / Tens. conmut. HIFI
	Schirmgitter Spg. / Screen-grid volt. / Tens. de grille - écran / Tens. di griglia schermo / Tens. de rejilla		Stummschaltung HiFi / Muting volt. HiFi / Commutation de silence HiFi / Silenzametro HiFi / Muting HiFi
			Schaltspg. HUB / Switching volt. deviation / Tens. commut. déviation / Tens. commut. deviazione / Tens. conmut. deviacion
	Vertikaler Ansteuerimpuls / Vert. drive pulse / Impulsion de commande verticale / Impulso di comando verticale / Impulso de control vertical		Stummschaltung Kopfhörer / Muting volt. headphone / Commutation de silence casque / Silenzamento cuffia / Muting auriculares
			Schaltspg. Koinz. / Switching volt. coinc. / Tens de commut. coinc. / Tens di commut. coinc. / Tens. conmut. coinc.
	VCR - Clock		Schaltspg. Koinz. mit Videoquelle verknüpft / Coinc. switching volt. linked with video source / Signal de coincid. combiné avec source video / Tens. di commut. a coinc. combinata con sorg video senal de coincidencia combinada con video
	Freigabe Anzeigebaustein / Display enable / Autorisation pour module indicateur / Modulo indicazione / Habilitacion modulo indicacion		Schaltspg. LED / Switching volt. LED / Tens de commut. LED / Commut. di commut. LED / Conmut. LED
	Vert. Gegenkopplung / Vert. feedback / Contre-reaction verticale / Controreazione vert. / Aliment. neg. vert.		Schaltspg. Leuchtpunktunterdrückung / Switching volt. beam spot suppression / Tens. de commut. suppress. du spot lumineux / Tens. soppr. punto luminoso / Tens. de conmut. filtro supresor del punto luz
	Video Signal / Video signal / Signal vidéo / Segnale video / Señal video		Schaltspg. LNC "Aus" / Switching volt. LNC "OFF" / Tens. de commut. LNC "OFF" / Tensione di commut. "Spento" LNC / Tension LNC "OFF"
	VT Daten / Teletext data / Données Teletexte / Linea dati Televideo / Data Teletexto		Stummschaltung / Muting / Silencieux / Silenziamento / Muting
	Videotext Clock / Teletext clock / Signal horloge Vidéotext / Clock Televideo / Clock Teletexto		Schaltspg. NF 1 / Switching volt. AF 1 / Tension commut. BF 1 / Tens. commut BF 1 / Tens. conmut. BF 1
	I ² C Bus: VT Daten / Teletext data / Données Vidéotext / Dati Televideo / Data Teletexto		Schaltspg. NF 2 / Switching volt. AF 2 / Tension commut. BF 2 / Tens. commut BF 2 / Tens. conmut. BF 2
	Y-Signal / Y Signal / Signal Y / Segnale Y / Señal Y		Schaltspg. NICAM / Switching volt. NICAM / Tens. de commut. NICAM / Tens. commut. NICAM / Tens. de conmut. NICAM
	Y - Signal - 50Hz vert., 15625Hz hor. / Y - Signal - 50Hz vert., 15625Hz hor. / Signal Y - 50Hz vert., 15625Hz hor. / Segnale Y - 50Hz vert., 15625Hz hor. / Señal Y - 50Hz vert., 15625Hz hor.		Schaltspg. Norm / Switching volt. Norm / Tens. de commut. standard / Tens. di commut. Norma / Tens. conmut. Norma
	Y - Signal - 100Hz vert., 31250Hz hor. / Y - Signal - 100Hz vert., 31250Hz hor. / Signal Y - 100Hz vert., 31250Hz hor. / Segnale Y - 100Hz vert., 31250Hz hor. / Señal Y - 100Hz vert., 31250Hz hor.		Schaltspg. PAL / Switching volt. PAL / Tens. de commut. PAL / Tens. commut. PAL / Tens. conmut. PAL
	Zwischenfrequenz / IF / FI / FI / FI		Schaltspg. Polarität / Switching volt. polarity / Tension commut. polarite / Tens. commut. polarita / Tens. conmut. polarizacion
	Schaltspg. AFC / AFC switching volt. / Tens. de commut. AFC / Tens. di commut. AFC / Tens. conmut. CAF		Schaltspg. Reset / Switching volt. Reset / Tens. commut. Reset / Tens. commut. Reset / Tens. conmut. Reset
	Schaltspg. AV / Switching volt. AV / Tens. de commut. AV / Tens. di commut. AV / Tens. conmut. AV		Schaltspg. -Schutzfunktion / Switching volt. -protective func. / Tens de commut. -sécurité / Tens. di commut. -funz di protez. / Tens. conmut. -proteccion
	Schaltspg. Bildamplitude / Switching voltage vertical amplitude / Tension de coupure amplitude d'image / Tensione di commutaz. ampiezza d'immagine / Tension de conmut. amplitude de imagen di commut. PAL / Tens. conmut. PAL		
	Schaltspg. BTX / Switching volt. BTX (Viewdata) / Tens. commut. Télétex / Tens. commut. VIDEOTEL / Tens. conmut. Teletexto		
	Schaltspg. Camera Wiederg. über C-AV Eingang/ Switching volt. cam. playback via C-AV input / Tens de commut pour lec. de camera par l'entree C-AV / Tens. de commut. in riproduz. cam tramite ingresso C-AV / Tens. de serv. reprod. camera a traves de la entrada C-AV		

	Schaltspg. SECAM / Switching volt. SECAM / Tens. de commut. SECAM / Tens. di commut. SECAM / Tens. conmut. SECAM
	Schaltspg. Standby / Switching volt. Standby / Tens. commut. Veille / Tens. commut. Standby / Tens. conmut. Standby
	Schaltspg. S-VHS / Switching volt. S-VHS / Tens. de commut. S-VHS / Tens. di commut. S-VHS / Tens. conmut. S-VHS
	Schaltspg. Ton 1-2 / Switching volt. sound 1-2 / Tens. commut. audio 1-2 / Tens. commut. son 1-2 / Tens. conmut. son 1-2
	Schaltspg. UHF / UHF switching volt. / Tens. de commut. UHF / Tens. di commut. UHF / Tens. conmut. UHF
	Schaltspg. VHF / VHF switching volt. / Tens. de commut. VHF / Tens. di commut. VHF / Tens. conmut. VHF
	Schaltspg. Videoquelle / Switching volt. video source / Tens. de commut. source video / Tens. di commut. sorg. video / Tens. conmut. video
	Schaltspg. Wischerkontakt / Switching voltage temp. contact / Tens. de commut. contact fugitif / Tens. commut. contatto / Contacto supresor tens. de commut.
	Schaltspg. ZF breit - schmal / IF switching volt. wide - narrow / Tens. commut. FI large - etroit / Tens. commut. FI larga - stretta / Tens. FI ancho - estrecho
	Schaltspg. Bandwahl / Band sel. switching volt. / Tens. de commut. select. bande / Tens. di commut. selez. banda / Tens. conmut. selec. banda
	14V Schaltspg. / 14V switching volt. / Tens. commut. 14V / Tens. conmut. 14V / Tens. de conmut. 14V
	22kHz Schaltspg. / 22kHz switching volt. / Tens. commut. 22kHz / Tens. conmut. 22kHz / Tens. de conmut. 22kHz
	0/3/6/9V Schaltspg. / 0/3/6/9V switching volt. / Tens. commut. 0/3/6/9V / Tens. conmut. 0/3/6/9V / Tens. de conmut. 0/3/6/9V
	Schaltspg. 4,5MHz / Switching volt. 4.5MHz / Tens. de commut. 4,5MHz / Tens. di commut. 4,5MHz / Tens. conmut. 4,5MHz
	Schaltspg. 50-60Hz / Switching volt. 50-60Hz / tens. de commut. 50-60Hz / Tens. di commut. 50-60Hz / Tens. conmut. 50-60Hz
	Regelspg. AFC / AFC contr. volt. / Tens. de regul. AFC / Tens. di contr. AFC / Tens. regul. CAF

Reglerbezeichnungen

	Zeilenbreite / Line width / Amplitude horizontale / Larghezza di riga / Amplitudo Horizontal
	Hor. Frequenz / Hor. Frequency / Fréq. horiz. / Frequ. orizz. / Frequ. horiz.
	Hor. Linearität / Hor. linearty / Linéar. Horizont / Linear. orizz. / Lineal. Horizontal
	Bildlage hor. / Hor. picture position / Cadrage horizont. / Posizione orizz. / Immagine / Centrado horizontal
	Ost-West Amplitude / East-West amplitude / Amplitude Est - Ouest / Ampiezza Est-Ovest / Amplitud E-O
	Ost-West Symmetrie / East-West symm. / Symm. Est-Ouest / Simm. Est-Ovest / Simetria E-O
	Bildamplitude / Frame ampl. / Ampl. verticale / Ampiezza d'immagine / Ampl. vertical

	Regelspg. AFC Satellitentuner / AFC contr. volt. SAT tuner / Tens. de regul. AFC tuner SAT / Tens. di contr. AFC Tuner SAT / Tens. regul. CAF Tuner SAT
	Feldstärkeabhängige Spg. / Fieldstrength-depnt volt. / Contr. automatique de gain / Tens. dipent. intens. campo / Contr. autom. de gain tens. CAG
	Regelspg. / Contr. volt. / Tens. de regul. / Tens. di contr. / Tens regul.
	Abstimmungspg. Tuner / Tuning volt. tuner / Tens. d'accord tuner / Tens. di sintonia tuner / Tens. sintonia tuner
	Regelspg. Verzög. / Delayed contr. volt. / Tens. de regul. retardee / Tens. regul. retardada
	Horizontale Ansteuerung / Horiz. drive / Synchr. lignes / Pilotaggio orizz. / Exitación horiz.
	31250Hz Ansteuerimp. für Zeilenendstufe / 31250Hz Triggering pulse for horiz. output / 31250Hz commande pour l'étage final lignes / Imp. Pilotaggio di 31250Hz per stadio finale di riga / Impulso de excitación 31250Hz para paso final de líneas
	Vert. Parabel / Vert. parabolic signal / Signal parabolique vert. / Segnale parab. vert. / Senal parabolica vert.
	Vert. Tastimpuls / Vert. Gating pulse / Imp. trame / Imp. a cadenza vert. / Imp. cuadro
	Vert. Tastimpuls 100Hz / Vert. Gating pulse 100Hz / Imp. trame 100Hz / Imp. a cadenza vert. 100Hz / Imp. cuadro 100Hz
	Vert. Sägezahn / Vert. saw tooth / Signal dent de scie / Dente di sega vert. / Dientede sierra vert.
	Vert. Tastimpuls / Vert. Gating pulse / Imp. trame / Imp. a cadenza vert. / Imp. cuadro
	Vert Sägezahn 100Hz / Vert saw tooth 100Hz / Signal dent de scie 100Hz / Dente di sega vert. 100Hz / Dientede sierra vert. 100Hz
	Vert. Parabel 100Hz / Vert. parabolic 100Hz signal / Signal parabolique 100Hz vert. / Segnale parab. vert. 100Hz / Senal parabolica vert. 100Hz
	Tastimpuls / Gating pulse / Impuls de declenchement / Impulso a cadenza / Imp. puerta
	Ref. Impuls hor. / Reference impulse hor. / Imp. de refer. hor. / Imp.

Adjustment Control Symbols

	Vert. Frequenz / Vert. frequency / Fréq. vert. / Frequ. vert. / Frequ. vert.
	Vert. Linearität / Vert. linearity / Linéarité vert. / Linear. vert. / Linealidad vert.
	Bildlage vert. / Vert. picture position / Cadrage vertical / Posiz. vert. / d'immagine / Centrado vert.
	Trapez / Trapezium / Trapèze / Trapezio / Trapecio
	Focusregler / Focus control / Réglage de focalisation / Regolat. di focalizz. / Control de foco
	Focusregler in vertikaler Richtung / Focus control in vert. position / Réglage de focalisation vert. / Regolat. di focalizz. in posizione vert. / Control de foco en direccion vert.
	Focusregler in horizontaler Richtung / Focus control in hor. position / Réglage de focalisation hor. / Regolat. di focalizz. in posizione hor. / Control de foco en direccion hor.





Alignment


All adjustment controls not mentioned in this description are adjusted during production and must not be re-adjusted in the case of repairs.

1. Chassis Board

Measuring Instruments: Oscilloscope with 10:1 test probe, colour test pattern, high resistance voltmeter

Cecks and adjustments after replacement or repair of:

- Power Supply: 1.1
- Horizontal Deflection: 1.2, 1.3, 1.9
- Colour Decoder Sync. Module: 1.7
- IF Amplifier, Tuner: 1.4, 1.5
- Tuning Module: 1.6, 1.8, 1.9
- Vertical deflection: 1.9
- CRT oder CRT panel: 1.3, 1.7

Alignment	Preparations	Alignment Process
1.1 +A Voltage	Set luminance to mimimum. Connect the voltmeter to the cathode of D681.	Set the control R654 to the voltage 124V .
1.2 Line sharpness	Select the convergence test pattern: Contrast to maximum Set the brightness so that the black background of the test pattern is just brightening.	With the focus control  at the split transformer adjust the horizontal lines for maximum sharpness.
1.3 Screen grid voltage U _{SG}	Feed in a test pattern. With the remote control adjust the screen brightness so that the grey areas just become dark. Switch the TV receiver to AV operation. Connect a high-ohmic voltmeter (series resistance approx. 220 kΩ) to the test points R, G, B and determine the test point having the highest voltage level.	With the control SG at the split transformer set the maximum voltage level to 155V...160V. 
1.4 Tuner-AGC	Feed in a standard test pattern in the upper range of the UHF band; RF ≥1.5mV (64dBμV, noise-free picture). Info Center → Special functions → Service → Code 8500 → Tuner AGC. Voltmeter: Contact 2.	With the buttons ◀ or ▶ adjust for 3.3V±0.4V. As an alternative, tune the TV station so that noise just starts to appear in the picture. Then tune in reverse direction until the picture just becomes noisefree. Store with OK.
1.5 AFC-Reference	Tune to a local station on a channel as low as possible at the desired programme position with standard channel spacing without fine tuning. Info Center → Special functions → Service → Code 8500 → AFC Reference.	Activate with OK. On activation of AFC Reference Automatic a rectified IF-voltage is measured at the AFC output of the IF amplifier which is used on station search as a comparative value for VCR-RF playback (station identification "AV") to readjust the modulator drift.
1.6 Colour match	Call up the programme position of the desired TV station. Infocenter → Special functions → Settings → Colour match.	Adjust with ◀ or ▶ buttons to make the signals coincide. Store with "OK".
1.7 White balance	Call up the White Balance menu via the Service Programme Info Center → Special Functions → Service → Code Number 8500. Contrast adjustment with this menu serves to check the white level between minimum and maximum contrast.	With ◀ and ▶ set the VG and VB values so that the white rectangular area in the middle of the picture becomes achromatic. Store with "OK".
1.8 Picture sharpness	Call up the programme position of the desired TV station. Infocenter → Picture menu → Sharpness.	Change the value with the ◀ and ▶ buttons.

Alignment	Preparations	Alignment Process
1.9 Picture Geometry	Info Center → Special functions → Service → Code 8500 → Geometry. Feed in a test generator or a standard test pattern. Attention! Start always with the "V-Middle" adjustment otherwise the other vertical deflection parameters would defy correct geometry adjustment. "V-Middle" adjustment with a video generator, eg. Grundig VG 1000:	Via the menu, select the geometry values for the vertical deflection, then set the values for the horizontal deflection. With the ◀ and ▶ buttons change the setting so that the G-Y vector (orange area in the centre of the picture) is just covered (typ. 30...33). Continue with the picture geometry adjustment via the menu and store.
	Reset: Under the menu item "Reset" an average data set from the ROM IC820 is stored. After inadvertent re-adjustment during servicing, these basic values can be re-loaded at any time.	Move the bar to "Reset". Press the "OK" button. With the i button return to the normal menu.

2. SAT Module (retrofitable)

Measuring Instruments: Oscilloscope with 10:1 test probe, colour test pattern.

Cecks and adjustments after replacement or repair of the SAT Module


Alignment	Preparations	Alignment Process
Video level	Switch the SAT receiver to SAT reception (eg. Astra) and set the correct video deviation (Astra 16MHz). Oscilloscope: EURO-AV-socket, contact 19 (75Ω termination). Trigger the CCVS signal to the vertical sync frequency.	With adjustment control R3848 at the SAT-Module set the amplitude of the vertical blanking gap in the CCVS signal to 1Vpp .

Platinenabbildungen und Schaltpläne


Layout of the PCBs and Circuit Diagrams

Chassisplatte / Chassis Board

Bestückungsseite, Ansicht von oben
Component side, top view




Solder side, bottom view



Oszillogramme Chassisplatte / Oscillograms Chassis Board




① 0,5V/cm, 2μs/cm



② 2V/cm, 2μs/cm




③ 0,2V/cm, 2μs/cm




④ 100V/cm, 2μs/cm




⑤ 100V/cm, 2μs/cm




⑥ 1V/cm, 20μs/cm




⑦ 1V/cm, 5ms/cm




⑧ 0,5V/cm, 5ms/cm




⑨ 50Hz 10V/cm, 5ms/cm




⑩ 2V/cm, 5ms/cm




⑪ 10V/cm, 20μs/cm



⑫ 5V/cm, 20μs/cm



⑬ 500V/cm, 10μs/cm




⑭ 5V/cm, 20μs/cm




⑮ 50 V/cm, 20μs/cm

Oszillogramme Chassisplatte / Oscillograms Chassis Board




19 20 V/cm, 20µs/cm


I2S CL
I2S D-IN
I2S WS




20 5V/cm, 5µs/cm
20A 5V/cm, 5µs/cm
20B 5V/cm, 5µs/cm




22 0,5V/cm, 5ms/cm




23 0,5V/cm, 5ms/cm




25 0,5V/cm, 20µs/cm



26 2V/cm, 5ms/cm




27 500mV/cm, 10µs/cm
28 500mV/cm, 10µs/cm
29 500mV/cm, 10µs/cm




30 1V/cm, 10µs/cm

SDA
SCL





32 5V/cm, 200µs/cm
33 5V/cm, 200µs/cm




35 1V/cm, 20µs/cm

Gesamtschaltplan / General Circuit Diagram


10.580-10585 BaU Baustein






Park Display Page 29504-105.67 105.67




10.580-10585 BaU Baustein







Bedieneinheit / Control Unit 29501-082.01



Abstimmbaustein / Tuning Module 29504-103.80


Servicearbeiten nach Bausteinwechsel: siehe Abgleich Seite 3-1 (1.6, 1.8) und 3-2 (1.9)
 Servicing work after replacing the module: see alignment page 3-3 (1.6, 1.8) and 3-2 (1.9)



NF-Baustein / AF Amplifier 29504-104.67



Tuner

Servicearbeiten nach Bausteinwechsel: siehe Abgleich Seite 3-1 (1.4, 1.5)
Servicing work after replacing the module: see alignment page 3-3 (1.4, 1.5)



1. 2. 3. 4. 5. 6. 7. 8. 9. 10. 11. 12. 13. 14. 15. 16. 17. 18. 19. 20. 21. 22. 23. 24. 25. 26. 27. 28. 29. 30. 31. 32. 33. 34. 35. 36. 37. 38. 39. 40. 41. 42. 43. 44. 45. 46. 47. 48. 49. 50. 51. 52. 53. 54. 55. 56. 57. 58. 59. 60. 61. 62. 63. 64. 65. 66. 67. 68. 69. 70. 71. 72. 73. 74. 75. 76. 77. 78. 79. 80. 81. 82. 83. 84. 85. 86. 87. 88. 89. 90. 91. 92. 93. 94. 95. 96. 97. 98. 99. 100. 101. 102. 103. 104. 105. 106. 107. 108. 109. 110. 111. 112. 113. 114. 115. 116. 117. 118. 119. 120. 121. 122. 123. 124. 125. 126. 127. 128. 129. 130. 131. 132. 133. 134. 135. 136. 137. 138. 139. 140. 141. 142. 143. 144. 145. 146. 147. 148. 149. 150. 151. 152. 153. 154. 155. 156. 157. 158. 159. 160. 161. 162. 163. 164. 165. 166. 167. 168. 169. 170. 171. 172. 173. 174. 175. 176. 177. 178. 179. 180. 181. 182. 183. 184. 185. 186. 187. 188. 189. 190. 191. 192. 193. 194. 195. 196. 197. 198. 199. 200. 201. 202. 203. 204. 205. 206. 207. 208. 209. 210. 211. 212. 213. 214. 215. 216. 217. 218. 219. 220. 221. 222. 223. 224. 225. 226. 227. 228. 229. 230. 231. 232. 233. 234. 235. 236. 237. 238. 239. 240. 241. 242. 243. 244. 245. 246. 247. 248. 249. 250. 251. 252. 253. 254. 255. 256. 257. 258. 259. 260. 261. 262. 263. 264. 265. 266. 267. 268. 269. 270. 271. 272. 273. 274. 275. 276. 277. 278. 279. 280. 281. 282. 283. 284. 285. 286. 287. 288. 289. 290. 291. 292. 293. 294. 295. 296. 297. 298. 299. 300. 301. 302. 303. 304. 305. 306. 307. 308. 309. 310. 311. 312. 313. 314. 315. 316. 317. 318. 319. 320. 321. 322. 323. 324. 325. 326. 327. 328. 329. 330. 331. 332. 333. 334. 335. 336. 337. 338. 339. 340. 341. 342. 343. 344. 345. 346. 347. 348. 349. 350. 351. 352. 353. 354. 355. 356. 357. 358. 359. 360. 361. 362. 363. 364. 365. 366. 367. 368. 369. 370. 371. 372. 373. 374. 375. 376. 377. 378. 379. 380. 381. 382. 383. 384. 385. 386. 387. 388. 389. 390. 391. 392. 393. 394. 395. 396. 397. 398. 399. 400. 401. 402. 403. 404. 405. 406. 407. 408. 409. 410. 411. 412. 413. 414. 415. 416. 417. 418. 419. 420. 421. 422. 423. 424. 425. 426. 427. 428. 429. 430. 431. 432. 433. 434. 435. 436. 437. 438. 439. 440. 441. 442. 443. 444. 445. 446. 447. 448. 449. 450. 451. 452. 453. 454. 455. 456. 457. 458. 459. 460. 461. 462. 463. 464. 465. 466. 467. 468. 469. 470. 471. 472. 473. 474. 475. 476. 477. 478. 479. 480. 481. 482. 483. 484. 485. 486. 487. 488. 489. 490. 491. 492. 493. 494. 495. 496. 497. 498. 499. 500. 501. 502. 503. 504. 505. 506. 507. 508. 509. 510. 511. 512. 513. 514. 515. 516. 517. 518. 519. 520. 521. 522. 523. 524. 525. 526. 527. 528. 529. 530. 531. 532. 533. 534. 535. 536. 537. 538. 539. 540. 541. 542. 543. 544. 545. 546. 547. 548. 549. 550. 551. 552. 553. 554. 555. 556. 557. 558. 559. 560. 561. 562. 563. 564. 565. 566. 567. 568. 569. 570. 571. 572. 573. 574. 575. 576. 577. 578. 579. 580. 581. 582. 583. 584. 585. 586. 587. 588. 589. 590. 591. 592. 593. 594. 595. 596. 597. 598. 599. 600. 601. 602. 603. 604. 605. 606. 607. 608. 609. 610. 611. 612. 613. 614. 615. 616. 617. 618. 619. 620. 621. 622. 623. 624. 625. 626. 627. 628. 629. 630. 631. 632. 633. 634. 635. 636. 637. 638. 639. 640. 641. 642. 643. 644. 645. 646. 647. 648. 649. 650. 651. 652. 653. 654. 655. 656. 657. 658. 659. 660. 661. 662. 663. 664. 665. 666. 667. 668. 669. 670. 671. 672. 673. 674. 675. 676. 677. 678. 679. 680. 681. 682. 683. 684. 685. 686. 687. 688. 689. 690. 691. 692. 693. 694. 695. 696. 697. 698. 699. 700. 701. 702. 703. 704. 705. 706. 707. 708. 709. 710. 711. 712. 713. 714. 715. 716. 717. 718. 719. 720. 721. 722. 723. 724. 725. 726. 727. 728. 729. 730. 731. 732. 733. 734. 735. 736. 737. 738. 739. 740. 741. 742. 743. 744. 745. 746. 747. 748. 749. 750. 751. 752. 753. 754. 755. 756. 757. 758. 759. 760. 761. 762. 763. 764. 765. 766. 767. 768. 769. 770. 771. 772. 773. 774. 775. 776. 777. 778. 779. 780. 781. 782. 783. 784. 785. 786. 787. 788. 789. 790. 791. 792. 793. 794. 795. 796. 797. 798. 799. 800. 801. 802. 803. 804. 805. 806. 807. 808. 809. 810. 811. 812. 813. 814. 815. 816. 817. 818. 819. 820. 821. 822. 823. 824. 825. 826. 827. 828. 829. 830. 831. 832. 833. 834. 835. 836. 837. 838. 839. 840. 841. 842. 843. 844. 845. 846. 847. 848. 849. 850. 851. 852. 853. 854. 855. 856. 857. 858. 859. 860. 861. 862. 863. 864. 865. 866. 867. 868. 869. 870. 871. 872. 873. 874. 875. 876. 877. 878. 879. 880. 881. 882. 883. 884. 885. 886. 887. 888. 889. 890. 891. 892. 893. 894. 895. 896. 897. 898. 899. 900. 901. 902. 903. 904. 905. 906. 907. 908. 909. 910. 911. 912. 913. 914. 915. 916. 917. 918. 919. 920. 921. 922. 923. 924. 925. 926. 927. 928. 929. 930. 931. 932. 933. 934. 935. 936. 937. 938. 939. 940. 941. 942. 943. 944. 945. 946. 947. 948. 949. 950. 951. 952. 953. 954. 955. 956. 957. 958. 959. 960. 961. 962. 963. 964. 965. 966. 967. 968. 969. 970. 971. 972. 973. 974. 975. 976. 977. 978. 979. 980. 981. 982. 983. 984. 985. 986. 987. 988. 989. 990. 991. 992. 993. 994. 995. 996. 997. 998. 999. 1000.

Bestückungsseite, Ansicht von oben
Component side, top view



CUC


schaltpläne / Circuit Diagrams

T Bildrohrröhre / CRT Panel 29305-122.03


Servicearbeiten nach Bausteinwechsel: siehe Abgleich Seite 3-1 (1.3.1.7)
Servicing work after replacing the module: see alignment page 3-3 (1.3.1.7)

CUC 6450

<https://windows7passion.fr/grundig.html>





ZF-Verstärker / IF Amplifier 29504-162.57








age 3-1 (1.4, 1.5)









Servicearbeiten nach Bausteinwechsel: siehe Abgleich Seite 3-2 (2.)
Servicing work after replacing the module: see alignment page 3-4 (2.)



Servicearbeiten nach Bausteinwechsel: siehe Abgleich Seite 3-2 (2.)
Servicing work after replacing the module: see alignment page 3-4 (2.)



SAT Baustein / SAT Module



GRUNDIGErsatzteilliste
Spare Parts List

D Btx * 32700 #

7 / 95

CUC 6450

SACH-NR. / PART NO.: 29701-095.01/02

| POS.
NR.
POS.
NO. | ABB.
NR.
FIG.
NO. | SACHNUMMER
PART NUMBER | ANZ.
QUA. | BEZEICHNUNG
D | DESCRIPTION
GB |
|----------------------------|----------------------------|---------------------------|--------------|---|---|
| 0001.000 | | 29504-201.21 | | CHIP-TUNER/ATA 1200 | CHIP TUNER/ATA 1200 |
| 0002.000 | | 29504-102.56 | X | ZF-VERSTAERKER .01 | IF AMPLIFIER .01 |
| 0003.000 | | 29504-103.80 | X | ABSTIMMBAUSTEIN | TUNING MODULE |
| 0004.000 | | 29504-104.67 | X | NF-BAUSTEIN | AF MODULE |
| 0004.100 | | 29504-162.56 | X | BAUSTEIN ZF .02 | IF MODULE .02 |
| WW. | | 29504-162.57 | X | BAUSTEIN ZF .02 | IF MODULE .02 |
| 0005.000 | | 29504-105.67 | X | BAUSTEIN FARB-SYNCHRON .01 | MODULE COLOUR-SYN. .01 |
| 0005.000 | | 29504-165.67 | X | BAUSTEIN FARB-SYNCHRON .02 | MODULE COLOUR-SYN. .02 |
| 0006.000 | | 29700-597.06 | | BAUSTEINHALTER .01 | MODULE HOLDER .01 |
| 0006.000 | | 29700-597.07 | | BAUSTEINHALTER .02 | MODULE HOLDER .02 |
| 0007.000 | | 29700-608.02 | | BUCHSENABDECKUNG | SOCKET COVER |
| 0008.000 | | 29303-119.06 | | PERIBUCHSE SW | PERI SOCKET BLACK |
| 0009.000 | | 29303-119.10 | | PERIBUCHSE BL .01 | PERI SOCKET BLUE .01 |
| 0009.100 | | 29303-119.35 | | PERIBUCHSE OR .02 | PERI SOCKET OR .02 |
| 0010.000 | △ | 29703-291.22 | | NETZSCHALTER | POWER SWITCH |
| WW. | △ | 29703-291.32 | | NETZSCHALTER | POWER SWITCH |
| 0011.000 | △ | 29303-399.26 | | GERAETESTECKER M.KABEL | APPLIANCE PLUG W.CABLE |
| 0013.000 | | 29303-153.16 | | MONTAGECLIP T644 | MOUNTING CLIP T644 |
| 0014.000 | | 29303-153.02 | | MONTAGECLIP IC366/430/T568 | MOUNTING CLIP IC366/430/T568 |
| 0015.000 | | 29303-153.12 | | MONTAGECLIP IC680/690 | ASSEMBLY CLIP IC680/690 |
| 0017.000 | | 29303-156.20 | | WAERMELEITFOLIE T644/IC680/690 | HEAT CONDUCTING FOIL T644/IC680/690 |
| 0018.000 | | 29303-156.23 | | WAERMELEITFOLIE T568 | HEAT CONDUCTING FOIL T568 |
| | | | | X = SIEHE GESONDERTE E-LISTE
WW. = WAHLWEISE | X = SEE SEPARATE PARTS LIST
WW. = OPTIONAL |

| POS.
NR.
POS.
NO. | SACHNUMMER
PART NUMBER | BEZEICHNUNG
D
DESCRIPTION
GB | POS.
NR.
POS.
NO. | SACHNUMMER
PART NUMBER | BEZEICHNUNG
D
DESCRIPTION
GB |
|----------------------------|---------------------------|---------------------------------------|----------------------------|---------------------------|---------------------------------------|
| C 103 | 8668-203-123 | ABBLOCK-C 0,1 UF -GR | C 623 | 8650-081-125 | HV-KERKO 1000PF 20% 1KV |
| C 264 | 8668-203-023 | ABBLOCK-C 0,1 UF -GR | C 624 | 8650-081-125 | HV-KERKO 1000PF 20% 1KV |
| C 271 | 8668-203-023 | ABBLOCK-C 0,1 UF -GR | C 626 | 8451-997-119 | ELKO 22 220UF 385V |
| C 276 | 8668-203-023 | ABBLOCK-C 0,1 UF -GR | C 632 | 8555-269-035 | KT/MKT 5/6 2700PF 5% |
| C 316 | 8668-203-023 | ABBLOCK-C 0,1 UF -GR | C 646 | 8650-067-486 | HV-KERKO 470PF 20% 2KV |
| C 511 | 8515-911-070 | FKP1 6800PF 3,5% 1600V | C 647 | 8531-510-687 | MKT 15 0,033UF 20% 630V |
| C 517 | 8515-722-120 | FOKO KF #28 0,68UF 10% 16 | C 648 | 8515-911-045 | FKP1 680PF 10% 1600V |
| C 518 | 8515-911-602 | FKP1 142PF 2,5% 2000V | C 664 | 8555-269-035 | KT/MKT 5/6 2700PF 5% |
| C 532 | 8426-098-061 | ELKO CB 4,7UF 350V | C 666 | 8660-098-238 | SI-KERKO B-SS 2200PF 20% |
| C 541 | 8555-268-255 | MKT 5/5 0,018UF 5% | C 672 | 8451-997-090 | ELKO 4 100UF 250V |
| C 542 | 8555-268-255 | MKT 5/5 0,018UF 5% | C 674 | 8650-081-129 | HV-KERKO 1500PF +50-20% |
| C 551 | 8650-067-046 | HV-KERKO 100PF 20% 1KV | C 677 | 8650-067-046 | HV-KERKO 100PF 20% 1KV |
| C 556 | 8650-067-046 | HV-KERKO 100PF 20% 1KV | C 686 | 8650-067-046 | HV-KERKO 100PF 20% 1KV |
| C 574 | 8515-722-231 | KF 22 0,26 UF 5% 160V | C 688 | 8650-067-046 | HV-KERKO 100PF 20% 1KV |
| C 598 | 8426-098-077 | ELKO CB 22UF 350V | C 912 | 8668-203-023 | ABBLOCK-C 0,1 UF -GR |
| C 601 | 8511-793-020 | MP 3 0,1 UF 20% 250VW RM | C 914 | 8668-203-001 | ABBLOCK-C 0,01 UF -GR |
| C 602 | 8511-793-020 | MP 3 0,1 UF 20% 250VW RM | C 922 | 8668-203-023 | ABBLOCK-C 0,1 UF -GR |
| C 603 | 8660-098-234 | SI-KERKO B-SS 1000PF 20% | C 924 | 8668-203-023 | ABBLOCK-C 0,1 UF -GR |
| C 604 | 8660-098-234 | SI-KERKO B-SS 1000PF 20% | | | |
| C 609 | 8563-732-425 | KF 25 0,1 UF 20% 250VW | D 111 | 8305-306-001 | IC ZTK 33 B DPD ITT |
| C 621 | 8650-081-125 | HV-KERKO 1000PF 20% 1KV | D 261 | 8309-215-006 | DIODE 1 N 4001 -GA |
| C 622 | 8650-081-125 | HV-KERKO 1000PF 20% 1KV | D 431 | 8309-720-510 | Z DIODE 51 C 0,5W |

| POS.
NR.
POS.
NO. | SACHNUMMER
PART NUMBER | BEZEICHNUNG
DESCRIPTION | <div>D
GB</div> | POS.
NR.
POS.
NO. | SACHNUMMER
PART NUMBER | BEZEICHNUNG
DESCRIPTION | <div>D
GB</div> |
|----------------------------|---------------------------|----------------------------|---------------------|----------------------------|---------------------------|----------------------------|---------------------|
| D 432 | 8309-215-045 | DIODE 1N4148 | | R 111 | 8705-370-099 | MOW LI 0922 12 KOHM 5% | |
| D 437 | 8309-215-104 | DIODE 1 N 4002 -GA | | R 262 | 8700-329-027 | KSW LI 0207-NB 12 OHM | |
| D 504 | 8309-214-010 | DIODE TD129 <<< | | R 431 | 8701-121-025 | KSW SI B LI 10 OHM 5% | |
| D 532 | 8309-215-020 | DIODE 1 N 4004 -GA | | R 436 | 8766-357-059 | MSW LI 0414 270 OHM 5% | |
| D 548 | 8309-200-021 | DIODE BAV21 ITT/TFK | | R 502 | 8705-328-993 | MOW LI 0411 0,51 OHM 10% | |
| D 551 | 8309-516-283 | DIODE BYV 28-200 RA 12,5/ | | R 504 | 8705-329-070 | MOW LI 0411 150 OHM 10% | |
| D 556 | 8309-516-283 | DIODE BYV 28-200 RA 12,5/ | | R 506 | 8701-118-033 | KSW SI B 22 OHM 5% -GA | |
| D 572 | 8309-201-005 | DIODE BA157 | | R 511 | 8705-279-077 | MOW AX 0922-GA 1,5 KOHM | |
| D 598 | 8309-204-268 | DIODE BYV 16 TFK/BYV 96E/ | | R 520 | 8705-221-271 | MOW AX 0411 820 OHM 10% | |
| D 620 | 8308-560-384 | GLR.SKB380C1500 L5B SEM/C | | R 525 | 8735-003-201 | DRW 0,75W 1 OHM 10% BWF23 | |
| D 641 | 8309-516-754 | DIODE BYT53B TFK/ EGP10B | | R 551 | 8705-227-019 | MOW AX 0411-GA 5,6 OHM | |
| D 647 | 8309-516-854 | DIODE BYT 54 M | | R 554 | 8700-329-009 | KSW LI 0207-NE 2,2 OHM | |
| D 648 | 8309-516-854 | DIODE BYT 54 M | | R 577 | 8705-329-221 | MOW LI 0411 6,8 OHM 10% | |
| D 653 | 8309-516-754 | DIODE BYT53B TFK/ EGP10B | | R 598 | 8705-329-025 | MOW LI 0411 10 OHM 5% | |
| D 661 | 8309-516-754 | DIODE BYT53B TFK/ EGP10B | | R 600 | 8765-049-157 | MSW AX 0414-GA 3,3 MOHM | |
| D 671 | 8309-517-178 | DIODE BYW 178/SK 3 G D08/ | | R 608 | 8311-200-010 | DUO-PTC | |
| D 674 | 8309-820-420 | DIODE MUR 420 | | R 623 | 8311-400-125 | VDR SD/1 250V -GR | |
| D 677 | 8309-820-420 | DIODE MUR 420 | | R 624 | 8766-349-161 | MSW LI 0414 4,7 MOHM | |
| D 686 | 8309-820-420 | DIODE MUR 420 | | R 627 | 8766-349-161 | MSW LI 0414 4,7 MOHM | |
| D 688 | 8309-517-172 | DIODE BYW 172 D/SK 3 G F0 | | R 654 | 8790-050-037 | ESTR.SK10-A 1,5 KOHM LIN | |
| D 692 | 8309-215-006 | DIODE 1 N 4001 -GA | | R 664 | 8705-369-043 | MOW LI 0617 56 OHM 5% | |
| D 694 | 8309-720-082 | Z DIODE 8,2 C 0,5W | | R 672 | 8705-329-321 | MOW LI 0411 100 KOHM 10% | |
| D 951 | 8309-215-045 | DIODE 1N4148 | | R 978 | 8700-329-013 | KSW LI 0207-NB 3,3 OHM | |
| D 981 | 8309-215-045 | DIODE 1N4148 | | R 992 | 8700-329-013 | KSW LI 0207-NB 3,3 OHM | |
| IC 102 | 8305-602-405 | IC X 24 C 04 XICOR | | SI 601 | 8315-621-027 | LOET-SI.-GR 2,5 A/T | |
| IC 260 | 8305-332-820 | IC TDA 2822 M SGS | | SI 624 | 8315-619-028 | LOET-SI.-GR 1,6 A/T | |
| IC 366 | 8305-337-262 | IC TDA 7262 SGS | | SI 677 | 8315-620-225 | LOET-SI.-GR 2 A/T | |
| IC 430 | 8305-338-350 | IC TDA 8350 Q | | SI 686 | 8315-618-200 | LOET-SI.-GR 1 A/T | |
| IC 631 | 8305-354-605 | IC TDA 4605/3 | | SI 688 | 8315-620-225 | LOET-SI.-GR 2 A/T | |
| IC 680 | 8305-204-455 | IC TDA 8137 SGS | | T 107 | 8303-207-548 | TRANS.BC 548 C | |
| IC 690 | 8305-204-317 | IC LM 317 T NSC/MOT/ | | T 505 | 8303-285-637 | TRANS.BC 637 | |
| IC 900 | 8305-433-440 | IC MSP 3400-15 | | T 531 | 8303-401-299 | TRANS.S 298 T TFK/PBF 259 | |
| IC 980 | 8305-365-114 | IC TEA 5114 A THO | | T 540 | 8303-205-548 | TRANS.BC 548 B | |
| L 112 | 8140-505-247 | DR A AX-GA 8,2UH | | T 568 | 8302-260-509 | TRANS.BU 508 D ON4152 | |
| L 113 | 8140-526-534 | DR AX 0411-GA 10UH | | T 644 | 8302-805-040 | TRANS.IRF BC 40 IOR | |
| L 114 | 8140-525-714 | DR AX 0411-GA 4,7UH | | T 680 | 8303-205-548 | TRANS.BC 548 B | |
| L 511 | 09246-850.51 | ZB-SPULE (90) COLOR | | T 695 | 8303-205-548 | TRANS.BC 548 B | |
| L 512 | 8104-982-056 | FERRITPERLE HF 70 BTL | | T 926 | 8303-207-548 | TRANS.BC 548 C | |
| L 520 | 29203-115.95 | LINEARITAETSREGLER (90) | | T 928 | 8303-207-548 | TRANS.BC 548 C | |
| L 554 | 8140-505-259 | DR A AX-GA 27UH | | T 929 | 8303-207-548 | TRANS.BC 548 C | |
| L 577 | 8140-505-249 | DR A AX-GA 10UH | | T 931 | 8303-207-548 | TRANS.BC 548 C | |
| L 601 | 29500-812.97 | FUNKENTSTOERDROSSEL | | T 932 | 8303-201-548 | TRANS.BC 548 | |
| L 648 | 8104-982-057 | FERRITPERLE-GA 3,6UH | | T 933 | 8303-207-558 | TRANS.BC 558 C | |
| L 653 | 8104-982-058 | FERRITPERLE-GA 1,7UH | | T 986 | 8303-203-558 | TRANS.BC 558 A | |
| L 671 | 8104-982-001 | FERRITPERLE-GA | | T 988 | 8303-201-548 | TRANS.BC 548 | |
| L 674 | 8104-982-001 | FERRITPERLE-GA | | T 989 | 8303-205-558 | TRANS.BC 558 B | |
| L 678 | 8104-982-001 | FERRITPERLE-GA | | T 992 | 8303-201-548 | TRANS.BC 548 | |
| L 687 | 8104-982-056 | FERRITPERLE HF 70 BTL | | TR 501 | 09246-865.04 | TRAFO TREIBER | |
| L 689 | 8104-982-014 | DAEMPFUNGSERLE | | TR 526 | 29201-031.60 | TRAFO DIODEN-SPLIT KPL | |
| L 901 | 8140-505-249 | DR A AX-GA 10UH | | TR 651 | 29201-421.97 | TRAFO SPERRWANDLER KPL | |
| L 907 | 8140-505-253 | DR A AX-GA 15UH | | | | | |
| L 908 | 8140-526-534 | DR AX 0411-GA 10UH | | | | | |
| Q 916 | 8382-439-185 | QUARZ 18,432 MHZ | | | | | |
| S601 | 99703 291 22 | INTER SECTEUR | | | | | |

Es gelten die Vorschriften und Sicherheitshinweise gemäß dem Service Manual "Sicherheit", Sach-Nummer 72010-800.00, sowie zusätzlich die eventuell abweichenden, landesspezifischen Vorschriften!

!

!


The regulations and safety instructions shall be valid as provided by the "Safety" Service Manual, part number 72010-800.00, as well as the respective national deviations.

GRUNDIG**Ersatzteilliste
Spare Parts List****D Btx * 32700 #****7 / 95****E 55-700 TOP/LOG TV-MAX
E 55-700/9 TOP/LOG TV-MAX**SACH-NR. / PART NO.: 9.21381-0175 BESTELL-NR. / ORDER NO.: G.CB 3575
SACH-NR. / PART NO.: 9.21381-0275 BESTELL-NR. / ORDER NO.: G.CB 4575COSMOS-SCHWARZ/COSMOS-BLACK
COSMOS-SCHWARZ/COSMOS-BLACK

| POS.
NR.
POS.
NO. | ABB.
NR.
FIG.
NO. | SACHNUMMER
PART NUMBER | ANZ.
QUA. | BEZEICHNUNG
D | DESCRIPTION
GB |
|----------------------------|----------------------------|---------------------------|--------------|--|--|
| 0001.000 | | 29625-726.02 | | GEHAEUSEVORDERTEIL DRUCK | CABINET FRONT COMP. |
| 0001.100 | | 29602-603.51 | | GRUNDIG-EMBLEM | GRUNDIG EMBLEM |
| 0001.200 | | 29633-640.01 | | IR-FENSTER DRUCK KPL. | IR-WINDOW COMP. CPL. |
| 0012.000 | | 29631-933.02 | | RUECKWAND M.GITTER OFB | REAR PANEL |
| 0012.100 | | 29631-919.01 | 2 | RUECKWANDHALTER | REAR PANEL |
| 0013.000 | | 29617-986.14 | | AUFKLEBER TYPE .01 | ADHESIVE LABEL;STICKER .01 |
| 0013.000 | | 29617-987.14 | | AUFKLEBER TYPE .02 | ADHESIVE LABEL;STICKER .02 |
| 0014.000 | | 29628-801.01 | 2 | CHASSISBEFESTIGUNG | CHASSIS FASTENING |
| | | 29656-003.74 | | MONTAGE-ZUBEHOER F.BILDROHR
KEIN E-TEIL | MOUNTING ACCESSORIES FOR CRT
NO SPARE PART |
| 0021.000 | | 29607-217.01 | 4 | SPULENKLAMMER | COIL CLIP |
| WW. | | 29607-218.01 | 4 | SPULENKLAMMER | COIL CLIP |
| 0024.000 | ⚠ | 09246-193.31 | | ENTMAGNETISIERUNGSSPULE | DEGAUSSING COIL |
| WW. | ⚠ | 09246-193.71 | | ENTMAGNETISIERUNGSSPULE | DEGAUSSING COIL |
| 0025.000 | ⚠ | 8300-020-534 | | BILDR.A 51 JSW 90X03 ORI | PICT.TUBE A 51 JSW 90X03 |
| WW. | ⚠ | 8300-020-532 | | BILDR.A 51 EAM 31X01 PHI | PICT.TUBE A 51 EAM 31X01 |
| WW. | ⚠ | 8300-020-533 | | BILDR.A 51 JAR 43X01 (MW) | PICT.TUBE A 51 JAR 43X01 |
| 0026.000 | ⚠ | 29201-360.01 | | ANODENKAPPE M. HOCHSPG.-KABEL | C.R.T. SOCKET |
| 0030.000 | | 29501-082.01 | | BEDIENEINHEIT | CONTROL UNIT |
| 0030.100 | | 29703-386.01 | | POTI-MOTOR | POTI-MOTOR |
| 0030.200 | | 29703-357.01 | 2 | TASTSCHALTER BEDIENTEIL | TACT SWITCH |
| 0030.300 | | 29303-390.28 | | KOPFHÖRERBUCHSE STEREO | EAR PHONE SOCKET |
| 0033.000 | | 29628-810.01 | | BASS-BOX KPL | BASS-BOX CPL. |
| 0033.100 | | 19154-031.03 | | LAUTSPRECHER TIEFTON BASS-BOX | LOUDSPEAKER WOOFER |
| 0035.000 | | 29305-008.30 | | CINCHBUCHSENPLATTE | CINCH SOCKET BOARD |
| 0035.100 | | 29303-168.05 | | CINCHBUCHSE 3-FACH | CINCH SOCKET |
| 0035.200 | | 29303-168.47 | | CINCHBUCHSE 2-FACH | CINCH SOCKET |
| 0036.000 | | 29628-811.02 | | SOUNDROHR KPL | SOUND TUBE CPL. |
| 0036.100 | | 19115-010.03 | 2 | HOCHTONFOLIENKALOTTE | TWEETER FOIL DOME |
| 0036.200 | | 19144-112.61 | 2 | LAUTSPRECHER MITTELTON | LOUDSPEAKER - MIDRANGE |
| 0036.300 | | 29628-804.02 | 2 | LS-GITTER ROHR OFB | LS-GRILLE |
| 0036.400 | | 29628-805.01 | | ZUSATZTEIL F.LS-MONTAGE | SUPPLEMENTARY |
| 0036.500 | | 29631-917.02 | | ABDECKUNG RECHTS OFB | COVER |
| 0036.600 | | 29631-918.02 | | ABDECKUNG LINKS OFB | COVER |
| 0045.000 | | 29501-640.01 | | TASTENSATZ | KEY SET |
| 0046.000 | | 29501-641.01 | | DREHKNOFF | ROTARY KNOB |
| 0047.000 | | 29633-681.01 | | BUCHSENABDECKUNG | SOCKET COVER |
| 0048.000 | ⚠ | 8290-991-316 | | NETZKABEL KPL | POWER CABLE CPL GWN9.22 |
| 0049.000 | | 29633-678.01 | | NETZTASTE | POWER KEY |
| 0050.000 | | 29642-059.06 | | TELEPILOT TP 720 | REMOTE CONTROL TP 720 |
| | | 29305-122.03 | X | BILDROHRPLATTE | PICTURE TUBE BOARD |
| | | 21381-941.01 | | BEDIENUNGSANLEITUNG .01 | INSTRUCTIONS MANUAL .01 |
| | | 21381-941.02 | | BEDIENUNGSANLEITUNG .02 | INSTRUCTIONS MANUAL .02 |
| | | 72010-017.50 | | SERVICE MANUAL | SERVICE MANUAL |
| | | 29701-095.01 | X | CHASSIS-FS-STEREO .01
CUC 6450
KEIN E-TEIL | CHASSIS-TV-STEREO .01
CUC 6450
NO SPARE PART |
| | | 29701-095.02 | X | CHASSIS-FS-STEREO .02
CUC 6450
KEIN E-TEIL | CHASSIS-TV-STEREO .02
CUC 6450
NO SPARE PART |
| | | | | X = SIEHE GESONDERTE E-LISTE
WW. = WAHLWEISE | X = SEE SEPARATE PARTS LIST
WW. = OPTIONAL |

| POS.
NR.
POS.
NO. | SACHNUMMER
PART NUMBER | BEZEICHNUNG
DESCRIPTION | <div>D</div> <div>GB</div> |
|----------------------------|---------------------------|----------------------------|----------------------------|
| C41006 | 8668-203-023 | ABBLOCK-C 0,1 UF -GR | |
| D81503 | 8309-215-045 | DIODE 1 N 4148 | |
| D81506 | 8309-215-045 | DIODE 1 N 4148 | |
| D81507 | 8309-215-045 | DIODE 1 N 4148 | |
| D81508 | 8309-215-045 | DIODE 1 N 4148 | |
| IC84001 | 8305-367-530 | IC TFMS 5300 | |

| POS.
NR.
POS.
NO. | SACHNUMMER
PART NUMBER | BEZEICHNUNG
DESCRIPTION | <div>D</div> <div>GB</div> |
|----------------------------|---------------------------|----------------------------|----------------------------|
| L41001 | 8140-526-060 | DR AX 0309-GA | 100UH |
| L41002 | 8140-526-060 | DR AX 0309-GA | 100UH |
| T81503 | 8303-284-369 | TRANS.BC 369 | |
| T81506 | 8303-284-369 | TRANS.BC 369 | |
| T81507 | 8303-287-368 | TRANS.BC 368 | |
| T81508 | 8303-287-368 | TRANS.BC 368 | |



Es gelten die Vorschriften und Sicherheitshinweise gemäß dem Service Manual "Sicherheit", Sach-Nummer 72010-800.00, sowie zusätzlich die eventuell abweichenden, landesspezifischen Vorschriften!



The regulations and safety instructions shall be valid as provided by the "Safety" Service Manual, part number 72010-800.00, as well as the respective national deviations.